


Parts Breakdown

Item 11428



Parts Breakdown

Item 11428

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
19605	Ring 16 for 11428	A5445	64363	Nut Din 917 M10 Inox for 11428	D013615	16967	Washer U65926 for 11428	R6512
19498	Rod Tray for 11428	B1304	19551	Foodholding Spacer for 11428	D5658A	36885	Washer U6592 10 Stainless Steel for 11428	R6530X
60301	Body for 11428	B1819A	36685	Clasp Arm for 11428	F3024	AN091	Washer Spec.Rasam.Ram24 (17x24x0.5) for 11428	R6836
36557	Bushing DU 25x28x30 for 11428	B6021	19581	Handle BT for 11428	I1913	17462	Washer 8x25x4 for 11428	R6869
AK403	Bushing DU 25x28x20 for 11428	B6056	36720	Gear DP50.00 Z20 M2.50 for 11428	I2420A	36925	Pin M.E.U6875 5x24 for 11428	S7549
19627	Bushing for 11428	B6082	17378	Spring Inox 8 6x0 8x23 for 11428	M7017	17474	Pin M.E.U6875 6x36 for 11428	S7553
19518	Handle Arm for 11428	B7821A	17430	Tray Assy for 11428	P4493	36986	Label for 11428	T1656
36586	Cellophane Paper - mm.130 for 11428	C1702	19833	Flat Bar for 11428	P4654A	19691	Grub Screw M6x6 for 11428	V6066
19531	Base for 11428	C6612	17440	Meat Grip Assy for 11428	P6876	19917	Screw BS for 11428	V7960
20460	Shaft for 11428	C7206	36866	Release Button for 11428	P8627	37110	Screw Speciale M10 for 11428	V8074
16928	Nut U5589 M6 for 11428	D0133	36871	Paper Holding for 11428	R1072			
19639	Nut M8 for 11428	D0135	19859	Food Holding for 11428	R1073			