

Parts Breakdown

Model MS-IT-0195-S 13607

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
33883	Sharpener Base for 13607	1a	14863	Thickness Adj. Plate for 13607	19b	33880	Washer for 13607	61b
33884	Washer for 13607	3a	14864	Strain Relief for 13607	20b	33881	Cam for 13607	62b
33885	Screw for 13607	4a	14865	Tie Rod for 13607	21b	14905	Cam Screw for 13607	63b
33886	Sharpener Shaft for 13607	5a	14866	Deflector Screw for 13607	22b	14906	Slide Support for 13607	64b
33887	Screw for 13607	6a	14867	Slice Deflector for 13607	23b	14907	Slide Pin for 13607	65b
33888	Nut for 13607	7a	14868	Screw for 13607	24b	14908	Screw TC for 13607	66b
33889	Screw for 13607	8a	14869	Circlip for 13607	25b	14909	Screw TC for 13607	67b
33890	Washer for 13607	9a	14870	Circlip for 13607	26b	14910	Nut for 13607	68b
33891	Screw for 13607	10a	14871	Pulley Bearing for 13607	27b	14911	Screw Testa CACC for 13607	69b
33892	Push Knob for Sharpener for 13607	11a	14872	Pulley for 13607	28b	14912	Screw for 13607	70b
33893	Ball Bearing for 13607	12a	14873	Belt for 13607	29b	14913	Plate for 13607	71b
33894	Spring for 13607	13a	14876	Shaft for 13607	30b	14914	Screw TC for 13607	72b
33895	Washer for 13607	14a	14877	Screw for 13607	31b	14915	Slide Bar Spring for 13607	73b
33896	Screw for 13607	15a	14878	Screw TC for 13607	32b	14916	Slide Bar for 13607	74b
33897	Washer for 13607	16a	13584	Blade 30-3-155 for 13607	33b	14917	Carriage for 13607	75b
33898	Sharpener Housing for 13607	17a	14880	Screw for 13607	34b	14918	Carriage Screw for 13607	76b
33899	Grinding Shaft for 13607	18a	AN148	Blade Cover (Fixed Sharpener) for 13607	35b	14919	Carriage Nut for 13607	77b
14883	Omcen F Stone 40x08x06 for 13607	19a	14882	Nut for 13607	36b	14920	Pin for 13607	78b
33901	Washer for 13607	20a	14885	Pin for 13607	39b	14921	Bearing for 13607	79b
33902	Nut for 13607	21a	14886	Pin for 13607	40b	14923	Screw for 13607	80b
33914	G Stone 40x08x06 for 13607	22a	14887	Support for 13607	41b	14924	Wing Nut for 13607	81b
33904	Honing Shaft for 13607	23a	14888	Spring for 13607	42b	14925	Plate for 13607	82b
33905	Sharpener Cover for 13607	24a	14889	Spring for 13607	43b	14926	Motor Adjustment Bar for 13607	83b
33906	Spring for 13607	25a	14890	Small Push Button for 13607	44b	14927	Spring for Adjustment Bar for 13607	84b
14849	Casing for 13607	1b	14976	Wrist Guard Plate for 13607	46b	14928	Motor for 13607	85b
14850	Screw for 13607	2b	14893	Meat Grip Knob for 13607	47b	14929	Screw for 13607	86b
14940	Index Knob for 13607	3b	14894	Screw TPSV for 13607	48b	34249	Ventosa (Guide Plate Support Cover) for 13607	87b
14852	Screw for 13607	4b	14895	Meat Grip for 13607	49b	14931	Motor Pin for 13607	88b
14853	Rivet for 13607	5b	14896	Pin for 13607	50b	14932	Circlip for 13607	89b
14854	Screw for 13607	6b	14897	Spring for 13607	51b	14933	Foot for 13607	90b
14855	Plate for 13607	7b	14898	Lock for 13607	52b	14934	Wrist Guard Screw for 13607	91b
14922	On / Off Switch for 13607	8b	14899	Meat Plate for 13607	53b	14935	Pulley Assembly for 13607	93b
14856	Capacitor for 13607	9b	14900	Screw for 13607	54b	21252	Bottom Cover for 13607	4d
14857	Clamp for 13607	10b	14901	Knob for 13607	55b	33907	Screw for 13607	13d
14858	Screw TC for 13607	11b	14902	Meat Plate Support for 13607	56b	33908	Safety Switch Holder for 13607	14d
14859	Power Cord for 13607	15b	14903	Carriage Knob for 13607	57b	33909	Pivot Chuck for 13607	15d
14860	Screw TE for 13607	16b	33877	Screw for Support Bar for 13607	58b	33882	Slide Support Complete for 13607	
14861	Washer for 13607	17b	33878	Support Bar for 13607	59b	14937	Complete Sharpening Assy. for 13607	
14862	Support for 13607	18b	33879	Screw for 13607	60b			