


Parts Breakdown

Model MS-IT-0330-L 13635

Sold Complete



Parts Breakdown

Model MS-IT-0330-L 13635

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
34636	Housing for 13635	A1	34671	Washer for 13635	A37	34706	Meat Deflector for 13635	A73
34637	Screw for 13635	A2	34672	Screw TC for 13635	A38	34707	Screw for 13635	A74
34638	Nut for 13635	A3	34673	Clip for 13635	A39	34708	Screw TE for 13635	A75
34639	Guide Plate Pin for 13635	A4	34674	Clip for 13635	A40	34709	Copper Rivet for 13635	A76
34640	Strain Relief for 13635	A5	34675	Bearing for 13635	A41	34710	Index Knob for 13635	A77
34641	Set Screw for 13635	A6	34676	Spacer for 13635	A42	34711	Screw Chrome for 13635	A78
34642	Set Screw for 13635	A7	15179	Belt TB2-360x12 for 13635	A43	34712	Light for 13635	A79
15202	Tie Rod for 13635	A8	34678	Spindle Pulley for 13635	A44	34713	Switch - On / Off for 13635	A80
34643	Nut for 13635	A9	34679	Bearing Shaft for 13635	A45	34714	Carriage Rail for 13635	A81
34644	Tie Rod Handle for 13635	A10	44857	Blade 330 40-3-270 for 13635	A46	34715	Bearing for 13635	A82
34645	Sharpener Tie Rod for 13635	A11	34681	Screw TPSV for 13635	A47	34716	Pin for 13635	A83
34646	Sharpener Support Bracket for 13635	A12	19284	Blade Shield for 13635	A48	34717	Set Screw for 13635	A84
34647	Washer for 13635	A13	34682	Rubber Washer for 13635	A49	34718	Set Screw PVC for 13635	A85
34648	Screw TE for 13635	A14	34683	Meat Grip for 13635	A50	34719	Slide Bar Spring for 13635	A86
34649	Sharpener Support Shaft for 13635	A15	34684	Meat Carriage Shaft Spring for 13635	A51	34720	Carriage Support for 13635	A87
34650	Sharpener Pin Spacer for 13635	A16	27887	Meat Grip Handle for 13635	A52	34721	Screw TC for 13635	A88
34651	Sharpener Pin for 13635	A17	34685	Meat Grip Handle Screw for 13635	A53	34722	Carriage Slide Bar for 13635	A89
33553	Finishing Stone for 13635	A18	34686	Plastic Dowel for 13635	A54	34723	Stop Plate for 13635	A90
34653	Washer for 13635	A19	34687	Meat Carriage Shaft for 13635	A55	34724	Tapping Screw for 13635	A91
34654	Set Screw for 13635	A20	34688	Meat Carriage for 13635	A56	34725	Foot for 13635	A92
34655	Nut for 13635	A21	34689	Set Screw for 13635	A57	34726	Capacitor for 13635	A93
34656	Screw TGS for 13635	A22	34690	Guide Plate for 13635	A58	34727	Capacitor Clamp for 13635	A94
34657	Sharpener Push Button for 13635	A23	34691	Meat Carriage Support for 13635	A59	34728	Screw TC for 13635	A95
34658	Ball Bearing for 13635	A24	27886	Knob for 13635	A60	34729	Motor Spring for 13635	A96
33032	45x9x6 Sharpening Stone for 13635	A25	34693	Meat Carriage Handle for 13635	A61	34730	Motor Bracket for 13635	A97
34660	Sharpener Pin for 13635	A26	34694	Wavy Washer for 13635	A62	34731	Wing Nut for 13635	A98
34661	Sharpener Pin Spring for 13635	A27	34695	Set Screw for 13635	A63	34732	Washer for 13635	A99
34662	Sharpener Cover for 13635	A28	34696	Cam for 13635	A64	34733	Hinge for 13635	A100
34663	Sharpener Body for 13635	A29	34697	Cam Screw for 13635	A65	34734	Motor Support Shaft for 13635	A101
34664	Sharpener Pin Spacer for 13635	A30	34698	Screw for 13635	A66	15203	Motor Tie Rod for 13635	A103
34665	Washer for 13635	A31	34699	Cam Guide for 13635	A67	34735	Motor for 13635	A104
34666	Screw TC for 13635	A32	34701	Screw TC for 13635	A68	14859	Power Cord for 13635	A105
34667	Sharpener Push Button for 13635	A33	34702	Cam Plate for 13635	A69	37449	Bottom Cover for 13635	C4
34668	Sharpener Pin Spring for 13635	A34	34703	Screw TC for 13635	A70	15187	Carriage Knob for 13635	
34669	Set Screw for 13635	A35	34704	Guide Plate Pin for 13635	A71	27539	Complete Sharpening Assy. for 13635	
34670	Stud Screw for 13635	A36	34705	Guide Plate Support for 13635	A72			