


PARTS BREAKDOWN

ITEM	MODEL
50003	VP-NL-0040-M



PARTS BREAKDOWN

ITEM	MODEL
50003	VP-NL-0040-M

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
35230	Vacuum Chamber Complete for 50003, 50004	0010	35250	Gas Nozzle Universal for 50003, 50004	0200	35270	Adj.Screw/Soc.Head M6x20 DIN916 A2 for 50003, 50004	0450
35231	Branch Pipe HFE-1 Ready for 50003, 50004	0020	35251	Hexagon Nut M8x1 Low DIN439B for 50003, 50004	0205	27781	Hexagon Flangenut M6 DIN6923 A2 for 50003, 50004	0460
35232	O-Ring 32x3 for 50003, 50004	0030	35252	Gas Valve for Gas Distribution for 50003, 50004	0210	35272	Hex.Socket Head Cap Screw M5x8 DIN912 A2 for 50003, 50004	0470
35233	Filter for 50003, 50004	0040	35253	Closing Plug Silicon Holder for 50003, 50004	0220	35273	Hinge Pin for 50003, 50004	0480
35234	Adj.Screw/Soc.Head M8x30 DIN916 A2 for 50003, 50004	0050	35254	Reducing Nipple 1/2x3/8 for 50003, 50004	0230	35274	Spring Collar for 50003, 50004	0490
27814	Hexagon Nut M8 DIN934 A2 for 50003, 50004	0060	35255	Distribution Block 4DVB/VP 3/8-1/4-4 for 50003, 50004	0240	35275	Safety Pin Hinge for 50003, 50004	0500
35236	Spring Ring M8 DIN127 A2 for 50003, 50004	0070	35256	Air Pressure Hose Blue 10x8 for 50003, 50004	0245	35276	Spring Ring 12mm DIN471 for 50003, 50004	0510
35237	Hex.Socket Head Cap Screw M5x30 DIN912 A2 for 50003, 50004	0080	35257	Insert Coupling Straight 1/4x10 for 50003, 50004	0250	27827	Flat Washer M10 D9021 A2 for 50003, 50004	0520
15722	Vacuum Valve without Decomp. Head 32mm for 50003, 50004	0090	35258	Blind Plug 3/8 MS/VN for 50003, 50004	0255	27826	Adj.Screw/Soc.Head M10x50 D916 A2 for 50003, 50004	0530
15723	Decompress Head Vacuumvalve 32mm for 50003, 50004	0100	15716	3-Way Valve for 50003, 50004	0260	35279	Self Locking Hexagon Nut M10 DIN985 VZ for 50003, 50004	0540
35240	Support Gas Cylinder for 50003, 50004	0110	30015	Square Hose Coupling 1/4x6 Ext. for 50003, 50004	0270	27819	Square Hose Coupling 1/8"x6 Ext. for 50003, 50004	0550
35241	Support Microswitch MV3000 for 50003, 50004	0115	35261	Brass Hose Coupling 1/4x8 Ext. for 50003, 50004	0350	15751	Decompress Filter 1/2" for 50003, 50004	0570
35242	Packing Branch Pipe Mobiles for 50003, 50004	0120	30015	Square Hose Coupling 1/4x6 Ext. for 50003, 50004	0360	35282	T-Screw-In Hose Coupling 1/8x6 Ext. for 50003, 50004	0580
15756	Gas Cylinder 1000320 (1X) for 50003, 50004	0130	15775	Micro Switch MV3003L for 50003, 50004	0370	35203	Plug Plastic 1/8 for 50003, 50004	0810
35244	Hexagon Screw M6x25 DIN933 A2 for 50003, 50004	0135	27823	Hexagon Nut M3 DIN934 A2 for 50003, 50004	0380	35284	Extension Piece Oil Drain for 50003, 50004	0820
35245	Hexagon Nut M6 DIN934 A2 for 50003, 50004	0140	27822	Castle Washer M3 for 50003, 50004	0390	35285	Valve 2/2 MA-222-003-P27-SAH 24 for 50003, 50004	0830
27786	Flat Washer M6 D9021 A2 for 50003, 50004	0150	35266	Distance Bush PCB Main for 50003, 50004	0395	35205	Brass Double Nipple 1/8 for 50003, 50004	0840
35247	Blind Stopper + O-Ring 1/4 MS/VN for 50003, 50004	0170	30011	Slotted Cheese Head Screw M3x20 A2 DIN84 for 50003, 50004	0400	35225	Silencer ID-CL 1/8 for 50003, 50004	0850
35248	Hose Coupling 1/2x10 Ext. for 50003, 50004	0180	27781	Hexagon Flangenut M6 DIN6923 A2 for 50003, 50004	0420	65830	Insert Plate 200-Basic for 50003, 50004	0900
35249	Elbow Coupling 10x1/4 for 50003, 50004	0190	27788	Adj.Screw/Soc.Head M6x25 DIN916 A2 for 50003, 50004	0430	35289	Vacuum Cover SB-520 Complete for 50003, 50004	1010

PARTS BREAKDOWN

ITEM	MODEL
50003	VP-NL-0040-M

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
35290	Sight Glass 200 (380x280x20) for 50003, 50004	1020	15784	TMBR AB193-TAB40 2 4-4 0A for 50003, 50004	2080	35330	Valve Cord CC2-02 for 50003, 50004	2260
35105	Sil.Profile Lidgasket 8mm 60 SH/25MTR for 50003, 50004	1030	15785	TMBR AB193-TAB60 4 0-6 0A for 50003, 50004	2081	35331	Cable Channel 40x40 for 50003, 50004	2280
35292	Lid Locker Hook V951L7-1BP for 50003, 50004	1040	15786	TMBR AB193-TAC10 6 0-10 0A for 50003, 50004	2082	35332	Cable Microswitch for 50003, 50004	2290
35293	Slotted Cheese Head Screw M3x5 A2 DIN84 for 50003, 50004	1050	15787	TMBR AB193-TAC16 10 0-16 0A for 50003, 50004	2083	35333	WM01 Feed Transformer Primary for 50003, 50004	2300
27788	Adj.Screw/Soc.Head M6x25 DIN916 A2 for 50003, 50004	1060	15781	TMBR AB193-TAPM Montage Sokkel for 50003, 50004	2085	35334	WM05 Looping Transformer Primary for 50003, 50004	2330
35295	Rod End Hinge Cover for 50003, 50004	1070	35315	Double Clamp 2.5-2 for 50003, 50004	2090	35335	WM06 Mas Pump-Threading Clamp for 50003, 50004	2340
27808	Adjusting Fork for 50003, 50004	1080	15771	Closed Contactor AB100-C09KJ400 24VAC for 50003, 50004	2110	35336	WM11 Pump Cable MAS-MBS 2.5 for 50003, 50004	2350
27809	Adjusting Fork Closing Pin for 50003, 50004	1090	35317	Earth Terminal PE 6-10 for 50003, 50004	2130	35337	WC04 Control Transformer Fuse-Clip for 50003, 50004	2360
35298	Cable Gland M20x1.5 Brass for 50003, 50004	1160	35318	Wire Clamp 6-2/2 AN for 50003, 50004	2140	35338	WE02 Ground Cord Machine-PE 2.5 for 50003, 50004	2370
35299	Handle GN-565-26-192-SW 800 for 50003, 50004	1200	35319	Rail JMV35SL 9-Hole 220mm for 50003, 50004	2150	35714	Interconnection Double MAS100C09 for 50003, 50004	2380
35300	Hexagon Screw M8x20 DIN933 A2 for 50003, 50004	1210	35320	Hex.Socket Head Cap Screw M4x8 DIN912 A2 for 50003, 50004	2170	15936	Sealbag 3000800-K(KL)L=340mm for 50003, 50004	3010
35301	Castle Washer Red Copper M8 for 50003, 50004	1220	34998	Flat Washer M4 D9021 A2 for 120/140 P32/Carriage Ring M4 for 50003, 50004	2175	31553	Pressure Beam H-2000 for 50003, 50004	3030
35302	Mounting Plate 160x455x5 for 50003, 50004	2000	35322	Earth Terminal M4 1x45-GR for 50003, 50004	2180	35342	Silicon Holder for 50003, 50004	3050
15792	Combi-Trafo P200/460V-S24/32V for 50003, 50004	2020	35323	End Plate Wire Connector for 50003, 50004	2190	35343	Silicon Holder for 50003, 50004	3055
35304	Earth Terminal PE 4-2/3 for 50003, 50004	2030	35324	Seal Cord C1-07 for 50003, 50004	2200	35344	Sealing Mechanism for 50003, 50004	3060
35305	End Fent for 50003, 50004	2050	35325	Seal Cord KK C1-22 for 50003, 50004	2205	15889	Seal Beam Single Seal L=500mm Complete for 50003, 50004	3100
35306	Fuse Clamp 2.5-2/ZSI for 50003, 50004	2060	35326	Control Cable CC1-01 for 50003, 50004	2210	35346	Seal Beam DS/1/495 for 50003, 50004	3110
35307	Fuse Keram.5x20 2.5A Delay for 50003, 50004	2070	35327	Network-Cord CM 1-11 for 50003, 50004	2220	35347	Seal Beam TS/4/495 for 50003, 50004	3120
15818	Fuse 5x20 4A Slow for 50003, 50004	2075	35328	Feed Main Switch CM2-04 for 50003, 50004	2230	35348	Seal Beam 8mm/4/495 for 50003, 50004	3130
15817	Fuse 5x20 8A Slow for 50003, 50004	2076	35329	Pump Cord CM4-09 for 50003, 50004	2250	27837	Hose (O2) Drago 6x13 for 50003, 50004	3290

PARTS BREAKDOWN

ITEM	MODEL
50003	VP-NL-0040-M

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
27836	Connecting Piece T-Piece 6mm for 50003, 50004	3310	35367	Bottom Section for 50003, 50004	4010	35384	Safety Clamp Vacuum Pump for 50003, 50004	4300
30019	Hose Clip Klemfa 12.8x14.8mm for 50003, 50004	3320	35368	Spring Control Box for 50003, 50004	4020	27786	Flat Washer M6 D9021 A2 for 50003, 50004	4310
35352	Cable Clamp 1x12mm DIN7257 for 50003, 50004	3330	35369	Swivel Castor Black ST.ST. 100mm for 50003, 50004	4030	27787	Hexagon Screw M6x16 DIN933 A2 for 50003, 50004	4320
35353	Self Tapping Screw PIAS 3.5x9.5 for 50003, 50004	3340	35370	Fixed Castor STST. for 50003, 50004	4040	35387	Vac Pump 040-132 230/400-3-50 E for 50003, 50004	5010
35354	Tube Alu 10x1mm L=400mm for 50003, 50004	3350	35211	Hexagon Screw M8x16 DIN933 A2 for 50003, 50004	4050	35388	Hose Clip ABA 32-44mm for 50003, 50004	5040
35355	Cable Clip 1x10mm DIN72571 for 50003, 50004	3360	35372	Castle Washer M8 for 50003, 50004	4060	15833	PVC Suction Hose HNA-32x42mm for 50003, 50004	5050
31554	Adj.Screw/Soc.Head M6x6 DIN916 A2 for 50003, 50004	3430	27814	Hexagon Nut M8 DIN934 A2 for 50003, 50004	4065	35390	Pipe Nipple Half 1/2 1 for 50003, 50004	5060
15842	Silicone T Profile 40 Shore One Meter for 50003, 50004	3490	35298	Cable Gland M20x1.5 Brass for 50003, 50004	4070	35391	Adj.Screw/Soc.Head M8x25 DIN916 A2 for 50003, 50004	5070
35358	Conical Compression Spring for 50003, 50004	3580	35375	Nut M20x1.5 MS for 50003, 50004	4075	35219	Flat Washer M8 D9021 A2 for 50003, 50004	5080
35359	Hexagon Bolt M6x40 DIN931 A2 for 50003, 50004	3590	35376	Cable Gland M20x1.5 Plastic for 50003, 50004	4080	27814	Hexagon Nut M8 DIN934 A2 for 50003, 50004	5100
27824	Castle Washer M6 for 50003, 50004	3600	35377	Lid Locker for 50003, 50004	4160	65754	Cover Protection 04-Control for 50003, 50004	9020
27787	Hexagon Screw M6x16 DIN933 A2 for 50003, 50004	3650	27822	Castle Washer M3 for 50003, 50004	4165	65753	Cap Wide Holder 04-Control for 50003, 50004	9030
27824	Castle Washer M6 for 50003, 50004	3660	35293	Slotted Cheese Head Screw M3x5 A2 DIN84 for 50003, 50004	4170	27789	Slott.Rais.Counter.Head Screw M4x10 DIN7985 A2 for 50003, 50004	9040
35507	Holing Block Silicon Holder HD-03 for 50003, 50004	3690	35380	Slotted Cheese Head Screw M4x12 A2 DIN84 for 50003, 50004	4180	35419	Sticker Tension + Warning for 50003, 50004	9420
35364	O-Ring 27x2.5 for 50003, 50004	3700	35381	Terminal Block 4-Pole for 50003, 50004	4200	27794	Sticker Machine Type for 50003, 50004	9430
35365	Mounting Screw Holing Block HD-03 for 50003, 50004	3740	35382	Cover Connection Block 4-Pole for 50003, 50004	4210	35223	Sticker 19x38 Yellow for 50003, 50004	9440
35366	Spacer Sil.Holder Gas 42mm for 50003, 50004	3750	35383	Slotted Cheese Head Screw M4x16 A2 DIN84 for 50003, 50004	4220	35224	Sticker 98x65 Yellow for 50003, 50004	9450